



If you have any questions or comments whatsoever or are unsure about any aspect of item operation then please feel free to contact us directly at: info@buddyequipment.co.za. Alternatively give us a call on + 27 (0)76 282 6565 and we will assist you with your query.

Buddy Cabinet - Installation Instructions

You will need the following tools:

1. Spirit level
2. Tape Measure
3. Straight Edge longer than a meter
4. A sharp pencil
5. A Hammer Drill
6. Diameter 7mm Masonry Drill Bit
7. Three (3) countersunk head screws (ø4.5mm x 45 mm) and plugs are supplied with your **Buddy Cabinet** for mounting it to the wall (included in your packaging).

Marking Out, Drilling and Mounting a Buddy Cabinet – Step by Step Procedure:

1. Mark out the vertical centre position of the cabinet on the wall.
2. Then make a horizontal mark 2100---2200mm up from the floor across the centre line.
3. Now with the wall cleat in place at the back of the cabinet, measure the distance down from the top of the cabinet to the centre of the pre---drilled holes in the wall cleat.
4. Using this measurement mark out the position of your first drilled hole on the centre line down from the 2100-2200mm horizontal line. Using a 7mm masonry drill bit, drill a hole 45 mm deep into the wall. Blow the debris out of the hole (Tip: use a drinking straw) and insert one of the plastic plugs, which should be part of your package.
5. Now lightly fasten the wall cleat to the wall ensuring the correct up and outward position of the cleat to receive the cabinet.
6. After levelling the cleat, mark out the position of the other two holes, drill these out with a 7mm masonry drill bit, each 45 mm deep, then after clearing the debris simply insert the plugs and secure the cleat to the wall using the balance of the screws supplied and tighten.
7. With someone to help you, lift the cabinet up over the cleat and ensuring that the back of the cabinet is flat in position, lower it down until the weight is taken up by the cleat mounted to the wall.
8. Note, there is some allowance provided for you to move the cabinet to the left or right should you wish to do so.
9. Note also that all Buddy products are supplied as untreated timber; we recommend that you protect your purchase by applying a suitable coating of oil or varnish.

Congratulations you are now ready to begin using your **Buddy Cabinet**